
EAGLE MANUFACTURING COMPANY WELLSBURG, WV 26070 www.eagle-mfg.com

INSTRUCTIONS ON HOW TO ASSEMBLE LID AND METAL BAND CLAMP WITH LEVER LOCK TO A DRUM FOR: MODEL 1610MB 14 GALLON LABPACK MODEL NO. 1654 20 GALLON SALVAGE DRUM AND MODEL NO. 1602 30 GALLON SALVAGE DRUM



- 1. PLACE LID ON TOP OF DRUM.
- 2. AFTER PLACING LID ON DRUM, MAKE SURE THE TOP OUTSIDE DIAMETER OF DRUM IS INSIDE LID AND AGAINST GASKET ALL AROUND DRUM BEFORE INSTALLING METAL BAND CLAMP.
- 3. OPEN METAL BAND CLAMP LEVER UNTIL IT STAYS OPEN.
- 4. PLACE THE BAND CLAMP OVER THE DRUM AND LID, WITH BAND ON A SLIGHT ANGLE, SO THE SIDE OPPOSITE THE LEVER GOES ON THE LID AND DRUM FIRST USING YOUR LEFT HAND. YOUR RIGHT HAND WILL BE ON THE LEVER.
- 5. CONTINUE HOLDING CLAMP TO DRUM WITH LEFT HAND WHILE LOWERING LEVER SIDE OF BAND WITH RIGHT HAND UNTIL BAND IS LEVEL AND ALL AROUND LID AND DRUM.
- 6. PULL THE LEVER TOWARD THE CLOSED POSITION UNTIL IT SNAPS INTO THE LOCKED POSITION AROUND THE LID AND DRUM.
- 7. NOW ROTATE THE LOCK TAB INTO THE SLOT AT THE END OF THE LEVER. MAKE SURE LOCK TAB ENTERS FROM TOP SIDE OF BAND ASSEMBLY.

CLOSURE INSTRUCTIONS FOR UN/DOT APPROVED CONTAINERS WITH SCREW LIDS

EAGLE MANUFACTURING COMPANY 2400 CHARLES STREET WELLSBURG, WV 26070 www.eagle-mfg.com

APPLICABLE TO THE FOLLOWING EAGLE PRODUCT MODEL NOS.:

1650 - 20 GALLON CAPACITY 1600SL - 30 GALLON CAPACITY 1661 - 65 GALLON CAPACITY 1690 - 95 GALLON CAPACITY

INSTRUCTIONS FOR USE:

TO OPEN: Remove threaded lid by rotating lid counterclockwise until fully disengaged from drum. Notches are provided in lid to accept a wooden 2" x 4" board to assist in unscrewing lid. Hammer impact on 2"x4" board may assist in loosening lid.

TO CLOSE: Assemble threaded lid to top of drum by aligning and placing lid onto open top of container, and then rotating lid in a clockwise direction until fully engaged. Notches are provided in lid to accept a wooden 2" x 4" board for additional tightening. Hammer impact on 2"x4" board may be used to assist in tightening lid.